



COMBINATION SAUNA JC200


Specification and assembly instructions

SPECIFICATIONS



Model	JC200
Dimensions	2000x1500x2005 mm
No. of persons	5
Wood	Hemlock, 50 mm
Glass	Transparent, tempered, 8 mm
Hinges	INOX
Control	Control panel with buttons
Operating time	Do 90 min
Temperature	IR up to 65 °C, finnish up to 90 °C
Ventilation	Yes
Connectivity	USB, Bluetooth, radio, app
Lighting	LED RGB starry night
Heaters	2450 W
Stove	6 kW, with thermostat, timer and volcanic stone
Plug in	Single-phase source: Schuko socket 230 V, 50Hz, 16 A fuse Three-phase source: Euro socket 400 V, 50Hz, 3x 16 A fuse
Weight	305 kg

COMPONENTS



1 Cover plate

2 Ceiling panel

3 Left side

4 Front side

5 Handle

6 Backplate

7 Right side

8 Control panel

9 Upper bench

10 Lower bench

11 Bottom

12 Stove

RECOMMENDED TOOLS



Screwdriver



Meter



Screwdriver



Screws



Water scale



Hex key



Knife




Ladder

ASSEMBLY TIPS

Please remove the transport packaging and check that your sauna has been delivered complete and undamaged before starting assembly. At least three people are required to assemble the sauna.



ASSEMBLY STEPS



1. Back plate



2. Left side



3. Upper bench



4. Lower bench



5. Right side



6. Bottom



7. Heater



8. Front panel



9. Handle






10 Ceiling panel




11 Cover panel




12 Assembled sauna


Installing the outer buckle



①



②



③

Connecting electrical components



1. Connect the power cable under the bench (for saunas with lower and floor heaters).



2. Connect the blue UTP cable from the control panel to the sauna control unit.



3. Connect the power cables between the control unit and the stove.

Installation of hinges, handle and cover



1. Install the hinges



2. Install the handle



3. Install the cover plate



CONNECTION TO THE ELECTRICAL NETWORK

FOR SAUNAS: JC200, JC180, JCP130

